



How To stop/delete a print job on a Sharp copier


If you need to delete or stop a print job on a Sharp copier that you have already released you need to click on the 'JOB STATUS' button in the top right hand corner or the touch panel (as shown below)




Highlight the job you want to delete if there are multiple listed, then touch the pop-out button shown below



Then select 'Stop/Delete'



You will then be prompted to confirm the delete/stop and the print job will then stop after it has finished the current page it is printing



Once you have stopped/cancelled all the jobs click on the 'Back' button

